


GETTING STARTED ON THE HEAT PRESS



FLAT PRESS - SETTING TEMP & TIME

Different materials will need different temperature and time settings. The temp/time settings for materials we sell are listed on left side of the cart the tumbler and hat press sit on.

- Turn on the heat press by flipping the red switch on the right side of the press.



Press the middle “OK” button once. The red light by “temp” is now lit; you can adjust the temp with the up and down buttons



Press the middle “OK” button again. The red light by “time” is now lit; you can adjust how long your press will take.




Press the middle “OK” button again. The red light is now gone and the screen says “LO.” ***It must say “LO” for the press to begin heating.***



FLAT PRESS – PRESSING YOUR MATERIAL

Grab this handle and swing the top of the press to the right. You now have room to place your material down.



Make a parchment sandwich! Place parchment under, in between (if you have layers like a shirt), and on top of your material. Place on the press bed.



Swing the top of the press back and then pull this handle all the way down until it locks into place. Use those muscles! It may take some effort.




The press will gently beep when the counter reaches 0. Pull the handle all the way up, remove the top parchment, and peek at your design before removing from the press.

TUMBLER PRESS - SELECT ATTACHMENT

We have these attachments for the mug press:

- 16/20/30 oz Skinny Tumbler
- 3 oz Espresso Mug
- 1.5 oz Shot Glass
- 11/15 oz Mug
- 6/10 oz Water Bottle
- 12 oz Tapered Latte Mug
- 17 oz Tapered Latte Mug



CHANGE OUT ATTACHMENTS



Unplug the attachment from the black box and unscrew the 4 screws to remove the attachment.

Choose your attachment that best fits your cup and reattach to the press.

While the press is **OFF**, insert your cup and pull the handle towards you to test the pressure. Adjust the knobs on the back of the machine accordingly for a tight fit.

TUMBLER PRESS - SETTING TEMP & TIME



Flip the red switch to turn on the press.

Press the **“OK”** button twice to change the temperature. Use the arrows to adjust.

Press **“OK”** again to change the time. Then again to set this temperature and time. The press will begin heating and beep loudly when desired temperature is reached.

TUMBLER PRESS - PRESSING YOUR CUP

Use **heat resistant tape** to secure your print to your cup. Then, wrap your cup in **parchment paper** like a taco, holding the ends of the parchment up so that you can carry your cup to the press.

Slide your cup into the press from the left side, ensuring your design will be fully inside the press. While holding the parchment taut, pull the handle towards you to press.

The press will beep when finished. Using gloves, slide the cup out from the left, take off the parchment, and peel off the paper.

****There will always be a gap at the top of the press. You do not want any of your design to be in this gap! If you are doing a full wrap, press your cup once, rotate the cup 180 degrees, and press again.**

